

# GOBO PROJECTOR – SETUP INSTRUCTIONS

***\*\*Keep all packaging materials after opening. Gobo must be returned in same box / packaging.\*\****  
***PLEASE HANDLE WITH CARE – PROJECTORS ARE FRAGILE!***


## **STEP 1: SETUP GOBO**

1. Plug gobo into outlet using power cord provided. It is pre-loaded with your design/color.
2. Place gobo projector on a table and point it where you want to project the image, such as a wall. Use the bracket to adjust the angle. See example picture below.



## **STEP 2: FOCUS THE IMAGE**

1. Locate the two knobs on top of projector. Twist to the left to loosen them slightly. (Loosen just enough so that the knobs can slide – do not loosen too much). Adjust focus by sliding the knobs. When projection image is clear, twist knobs to the right to lock into place. (Do not over tighten!).




***.... Continued on Reverse Side***

### **STEP 3: ALIGN THE IMAGE (OPTIONAL)**

If you need to align or rotate your image, locate the red rectangle with small white switches on back of gobo. (See photo on reverse side). The #1 and #4 switches should be in “on” position by default.

**To rotate the image**, slide Switch #4 down (“off” position). You will see the image rotate continuously. When the image is aligned to your desired position, slide Switch #4 back up (“on”). This will lock the image in place.



***TROUBLESHOOTING:*** Reset gobo by sliding all white switches down into “off” position. Then slide switches #1 & #4 back up into the “on” position. You can also call 305-921-4099 for assistance.

## **ADJUSTING SIZE OF PROJECTION IMAGE**

The size of the projection image depends on how far away you place the projector from the wall. The farther away, the larger the image will be. For example, if the projector is 20 feet away from the wall, the image will be about 6.6 feet wide. At 10 feet away from the wall, the image will be 3.3 feet wide.

## **YOU'RE DONE!**

### **RETURN INSTRUCTIONS**

1. Put gobo back in the plastic case. Remove any original shipping labels, and affix pre-paid return label provided. Lock the case using the 2 cable ties provided (see picture at right).
2. Drop off package at any FedEx location. (Package CANNOT be left at a drop box, it must be a physical FedEx store). Get a receipt for your records.
3. **Misplaced your return labels?** No problem! Email [info@rentmywedding.com](mailto:info@rentmywedding.com) or call 305-921-4099 and we'll email you the labels.



### **RETURN DATE**

Unless otherwise noted, your return is due back to FedEx 2 days after your event date. (If your return date falls on a Sunday or holiday, you can return the following day).